

PHILIPS

AN INTERFACE USING STANDARD ASCII COMMANDS IN CONJUNCTION WITH LIGHTOLIER CONTROLS MULTISet SYSTEMS

Project:

Location/Type:

Description

The MultiSet/MultiSet Pro - MS232 Interface provides interconnection between a MultiSet/MultiSet Pro System and equipment that utilizes standard ASCII commands and can connect via RS-232 or RS-485.


The system is comprised of two components - the interface outlet and the MS232 interface box. One interface is required per MultiSet System.

Features

- One RS-232 (9-pin serial, female DB-9) terminal per interface
- One RS-485 5-pin terminal strip per interface, permitting connection with up to 31 MS232 interface devices
- 8-position dip switch allows for individual identification of up to 31 MultiSet/MultiSet Pro Systems
- Easy to read LED status lights with test switches, including ON, A, B, C, D, and OFF
- Interface provides ASCII input capabilities, as well as feedback status from controlling equipment
- Interface box mounts easily to wall with mounting bracket provided
- Single gang 4-pin receptacle is provided that interconnects the MultiSet/MultiSet Pro system to the receptacle via 14/3 w/ground
- Interface comes standard with a 4-pin connector that easily plugs into the provided 4-pin receptacle
- Fully supports MultiSet Pro. Extended scenes are reached by pressing multiple buttons and are displayed by illuminating multiple LED's.


Com Port Settings

- Baud Rate: 1200-9600
- 8 Bit
- No Parity
- 1 Stop Bit



1. RS-232 9-pin serial D-subminiature female connector
2. Communication Status LEDs
3. RS-485 terminal
4. 8-position dip switch (See detail below)
5. Status LEDs with test switches

Dip Switch Bank Detail



MULTISET/MULTISET PRO - MS232 INTERFACE

Product
Specifications

Specifications

This device is compatible with Lightolier MultiSet Five-Scene and MultiSet Pro 13-Scene Dimming Systems. One MS232 interface is required for each MultiSet/MultiSet Pro system. The MS232 is also compatible via the RS-485 connection with other MS232's, the WB232, and CL232 integration products.

The housing unit has a black enamel finish and measures 5" wide by 5 1/4" tall by 1 1/2" deep. The housing may be wall-mounted using the mounting bracket provided with the unit.

The device consists of an interface box and a 4-pin line voltage plug with receptacle and faceplate. The receptacle is to be mounted in a single-gang wall box. The interface box provides control of preset scenes and master raise/lower. It includes one 9-pin serial connector and one RS-485 5-pin connector (only 3 pins used).

The baud rate for the RS-232 may be selected via 2-positions of the 8 position dip switch for setting 1200, 2400, 4800 or 9600 baud, 5-positions of the dip switch allows for individual identification of up to 31 MultiSet systems and one position is used to set end-of-line. The RS-485 has a baud rate of 4800.

The MS232 has receive and acknowledge LED's, in addition to providing two-way communication using an ASCII command set. The MS232 also includes scene status LED's and test switches for On, A, B, C, D and Off. Extended scenes in MultiSet Pro can be accessed and displayed using multiple switch presses and multiple LED's. MultiSet systems connect to the MS232 via 14/3 w/ground.

MS232 Protocols

Command	Action	Response
01N<CR>	Lights On (Fade)	01n
01IN<CR>	Lights On (Instant)	01n
01X<CR>	Lights Off (Fade)	01x
01IX<CR>	Lights Off (Instant)	01x
01A<CR>	Recall Preset A (Fade)	01a
01IA<CR>	Recall Preset A (Instant)	01a
01B<CR>	Recall Preset B (Fade)	01b
01IB<CR>	Recall Preset B (Instant)	01b
01C<CR>	Recall Preset C (Fade)	01c
01IC<CR>	Recall Preset C (Instant)	01c
01D<CR>	Recall Preset D (Fade)	01d
01ID<CR>	Recall Preset D (Instant)	01d
01E<CR>	Recall Preset E (Fade)	01e
01IE<CR>	Recall Preset E (Instant)	01e
01F<CR>	Recall Preset F (Fade)	01f
01IF<CR>	Recall Preset F (Instant)	01f
01G<CR>	Recall Preset G (Fade)	01g
01IG<CR>	Recall Preset G (Instant)	01g
01H<CR>	Recall Preset H (Fade)	01h
01IH<CR>	Recall Preset H (Instant)	01h
01I<CR>	Recall Preset I (Fade)	01i
01II<CR>	Recall Preset i (Instant)	01i
01J<CR>	Recall Preset J (Fade)	01j
01IJ<CR>	Recall Preset j (Instant)	01j
01K<CR>	Recall Preset K (Fade)	01k
01IK<CR>	Recall Preset k (Instant)	01k
01L<CR>	Recall Preset L (Fade)	01l
01IL<CR>	Recall Preset l (Instant)	01l
01FN<CR>	Begin System Raise	01n
01FS<CR>	Stop Raise / Lower	01n
01FX<CR>	Begin System Lower	01n
99X* <CR>	Global Command - Can be used for all functions	All systems will respond with normal message
99? <CR>	Poll all systems	All systems will respond with status


***NOTE:** "X" stands for your selection of the "A" scene or "ON". i.e. 99A<CR> or 99N<CR>

NOTE: Dimmers can be raised or lowered in 5% increments by using the lowercase box ID code letters "a" to "t" with the "N" or "X" command. For example:


##aN<CR>		Raise system dimmers 5%		##n		
##aX<CR>		Lower system dimmers 5%		##n		
a = 5%	b = 10%	c = 15%	d = 20%	e = 25%	f = 30%	g = 35%
h = 40%	i = 45%	j = 50%	k = 55%	l = 60%	m = 65%	n = 70%
o = 75%	p = 80%	q = 85%	r = 90%	s = 95%	t = 100%	

KEY: "##" stands for the box ID code 01-31.

Wiring Diagram



Dimensions



We reserve the right to change details of design, materials and finish in any way that will not alter the installed appearance or reduce function performance.

Philips Lighting Controls
2828 Trade Center Dr., Suite 130B
Carrollton, TX 75007

For technical/sales assistance, call: 1-800-526-2731

Made in U.S.A.

www.philips.com/lightingcontrolsna

P/N 87-0080B